

Safe Jack

Product Range



PROQUIP
VALUE ADDED PRODUCTS

www.proquip.com.au

2019

BOTTLE JACK RECOVERY KIT



INCREASE THE LIFTING RANGE OF YOUR BOTTLE JACK

PART No. 14110

Benefits

- Increases safety
- Makes jacking easy in a variety of ways
- Extension Screw Collar increases stability
- Extends the range and usefulness of your jack

Feel safer during lifting and jacking operations. Be prepared for any lifting task the road might throw at you. Feel safer knowing that the jack isn't going to slip off an axle or topple off a stack of blocks.

The Bottle Jack Recovery Kit combines all of the most useful tools to turn a 4 or 6 ton bottle jack into a compact, powerful, and safe lifting tool. Add the optional Safe Jack Universal Stabiliser Base Plate and Insert Plate system to decrease ground loading and increase stability.

Lift Range: 8 inches to 36 inches
(Additional extensions can increase range).

Features

- Fits Jack ram diameter: 31.7mm - 33mm
- Lift range of 8—36 inches
- Use to create many height combinations
- Lift at axle, frame or other lift point
- Durable steel construction
- Extensions and pads Made in USA

What's Included:

- 1 x Heavy Duty Carry Bag
- 1 x 3" Bottle Jack Extension
- 1 x 6" Bottle Jack Extension
- 1 x Adjustable Bottle Jack Extension
- 1 x Axle Tube Pad
- 1 x Flat Pad
- 1 x Extension Screw Collar

6 TONNE HYDRAULIC BOTTLE JACK

CONFORMS TO AUSTRALIAN STANDARD AS2693:2007



PART No. 14600

Part No.	Capacity	Min. Height	Max. Height	Hydraulic Stroke	Extension Screw	Handle Length	Saddle Diameter	Base Size Length	Base Size Width	Net Weight
14600	6 Tonne (6,000 kg)	220mm	415mm*	152mm	70mm	450mm	31.5mm	159mm	96mm	5.9 kg

*Without Safe Jack Extensions, Collar and jack pads
- Add an extra 53cm with Safe Jack Recovery Kit extensions and pads.

BOTTLE JACK EXTENSION SCREW COLLAR

ANY JACK CAN BE USED WITH THE RECOVERY KIT

The Extension Screw Collars are installed on bottle jacks to provide the proper fit for jack extensions and jack pads, but they also give the operator 100% of the usable stroke of the jack by extending and supporting the bottle jack extension screw.

The collars are simple to install in a few seconds, and can be removed just as easily. They are designed to work with 6, 12 or 20 tonne rated bottle jacks that fall within the minimum and maximum sizes as shown below.






PART No. 14125



PART No. 14126



PART No. 14127



BOTTLE JACK ACCESSORIES

INCREASE THE VERSATILITY OF YOUR BOTTLE JACK

BOTTLE JACK 12 TONNE & 20 TONNE RAM ADAPTORS



PART No. 14145

PART No. 14140

The Safe Jack™ Ram Adaptors are an easy way to extend the reach of 12 and 20 tonne jacks without having to pile blocks and cribbing under them.

The Ram Adaptor simply slips over the ram of typical 12 or 20 tonne bottle jacks, and also couples with the Safe Jack™ Bottle Jack Recovery Kit Extensions.

The combination of adaptors and extensions is far safer than a jack and cribbing system because all the parts are firmly connected. Even if things shift, the jack and extensions remain securely together.

BOTTLE JACK ROUND JACK PAD



PART No. 14150

Up to 2.5" Round Jack Pad

Safe Jack™ Round Jack pad can be used on axle tubes or other rounded structures up to 2.5 inches in diameter.

It fits over the typical 1.25 inch diameter bottle jack ram. It can also be coupled with any of the jack ram extensions to move the pad closer to the load.

Safe Jack™ Round Jack Pad has 12 times the surface area of the jack ram alone, meaning more stability and safety.

BOTTLE JACK SEMI AXLE TUBE JACK PAD



PART No. 14160

Up to 5" Round Semi Axle Tube Pad

Designed to fit the axles of Semi Trucks and trailers up to 5 inches in diameter, these axle tube pads are coupled with typical 20 tonne bottle jacks (with 54mm Ram).

The pads low profile design makes it easy to place and maximizes the usable stroke.

UNIVERSAL STABILISER BASE PLATE



USE IN CONJUNCTION
WITH THE BOTTLE JACK
INSERT PLATE AND HI-LIFT INSERT
PLATE FOR THE ULTIMATE SUPPORT

VASTLY INCREASE THE STABILITY OF YOUR JACK

PART No. 14000

Benefits

- Increases Safety and Stability
- Allows greater lifting force without sinking into soft surfaces
- Provides Stability against tip-overs
- Reduces ground loading

Features

- Inserts easily slide into Universal Base Plate
- Quick Release pin allows fast setup
- Steel construction & durable powdercoat finish
- Heavy Duty welded handles for easy placement
- Low Height allows for simple storage

DESIGNED TO USE WITH:

**PART No. 14011
HI-LIFT JACK INSERT PLATE**



**PART No. 14121
BOTTLE JACK INSERT PLATE**



BOTTLE JACK BASE PLATE INSERT

REDUCE THE GROUND LOADING OF YOUR JACK



PART No. 14121

USE IN CONJUNCTION WITH
THE UNIVERSAL STABILISING
BASE PLATE FOR THE
ULTIMATE SUPPORT

Benefits

- Increases safety
- Increases stability by up to 3 times
- Reduces ground loading to as little as 25%

The Bottle Jack Base Plate Insert makes bottle jacks safer to use and more productive.

The Insert Plate fits most jacks up to 20 tons. Jacks are easily attached to the plate with tabs, screws and wing nuts using a generous number of mounting options.

Just by adding the Insert plate, the jack becomes two to three times more stable on any surface. This is due to the base being wider, and the footprint becoming up to four times larger, therefore reducing the ground pressure up to 25% of using the jack alone.



Insert with
Universal
Base Plate

Features

- Insert easily slides into Universal Base Plate
- Steel construction
- Durable powder coat finish
- Use with most bottle jacks up to 20 ton
- Includes mounting hardware

This is very important if you're using the jack on anything other than a flat, hard surface.

Best of all, the Insert plate locks into the Universal Base Plate, which again increases stability four to five times, and gives you up to eight times the support area.

The larger the support area, the more stable and secure your jack will become.

- Insert Plate Dimensions: 20cm x 18cm
- Bottle Jack can be purchased separately.

HI-LIFT JACK BASE PLATE INSERT

REDUCE THE GROUND LOADING OF YOUR JACK



PART No. 14011

**USE IN CONJUNCTION WITH
THE UNIVERSAL STABILISING
BASE PLATE FOR THE
ULTIMATE SUPPORT**

Benefits

- Includes mounting hardware
- Increases safety and stability
- Hugely reduces ground loading
- Quick release pins for fast installation/disassembly

The Hi-Lift Jack Base Plate Insert used in conjunction with the Universal Stabiliser Base Plate, makes Hi-Lift Style jacks safer to use and more productive.

This is a crucial jack accessory for Emergency Services, Off Road, 4X4, Camping, Defence Force and Agricultural uses.

The Universal Stabiliser Base Plate provides stability against tip-overs and added flotation for soft surfaces. This makes your Hi-Lift jack far safer to use and much more reliable than a jack used without the Base Plate.



Insert with
Universal
Base Plate

Insert with
Universal
Base Plate

Features

- Insert easily slides into Universal Base Plate
- Steel construction & durable powdercoat finish
- Aircraft-grade cable construction
- Use with most Hi-Lift style jacks
- Fits Jack footprint up to: 18cm x 10cm

When using the Safe Jack Universal Stabiliser Base Plate you are able to exert greater lifting force without sinking into the ground, which is vital if you are jacking a vehicle or pulling a stump. You will see that it installs in seconds and does not limit jack operation. The larger the support area, the more stable and secure your jack will become. Note: Hi-Lift Jack not included.

PART No. 14015

Stabiliser Cables for
60" Hi-Lift Jacks



HI-LIFT JACK SECURE LIFTER

HOLD YOUR JACK PARALLEL TO THE LOAD



PART No. 14020

Benefits

- Greatly improves jack usefulness
- Increases safety and stability
- Lift loads that are too low for jack
- Lift loads forward of jack base

The Patent Pending Secure Lifter for Hi-Lift jacks is a very useful accessory for 4X4 enthusiasts, Farms and Plantations, Military applications and Industrial Plant Operations. It provides for the safe and secure attachment of a load to a Hi-Lift jack and provides a stabiliser that holds the jack parallel to the load being lifted. This makes the jack far safer to use and more useful than a jack without it.

Use the Universal Stabiliser Base Plate with

Features

- No tools required — Quick pin install
- Steel construction & durable powdercoat finish
- Securely attach to load with chain or strap
- Use with most Hi-Lift/Farm style jacks

the Secure Lifter to maximise safety, stability and productivity.

Specifically, the Secure Lifter is vital to lift loads that would be forward of the jack base, and to lift loads that are situated where it is not possible to place the jack underneath the load.

Use it to pick up tractor tyres, lift vehicles out of ruts or off obstacles, lift machinery, shipping containers, boat trailers etc.

It also makes post, shrub and tree stump removal a piece of cake.

PART No. 14025

6ft Chain
(Grade 30/2650 lbs)



PART No. 14026

Secure Lifter
Polyester Sling



HI-LIFT JACK STABILISER LEGS

TURN YOUR HI-LIFT JACK INTO A TRIPOD JACK



PART No. 14030

Features

- No tools required — Quick pin install
- Steel construction & durable powdercoat finish
- Securely attach to load with chain or strap
- Use with most Hi-Lift/Farm style jacks

The Patent Pending Safe Jack Stabiliser Legs attachment for the Hi-Lift Jack turns the jack into a powerful and stable tripod jack.

The extra stability and resistance makes it capable of pulling or lifting many things including; pulling stumps, scrub, posts and pumps.

Combine the Stabiliser Legs with the Universal Stabiliser Base Plate and the Secure Lifter that fits on the lifting nose of the jack, and you have a powerful system for getting things done easily.

The legs attach and detach in seconds with two quick release pins.

Legs are 56" long with 5" x 5" inch support pads.



WHEEL CHOCKS & SUPPORT STAND BASE



PRODUCTS TO
ENSURE YOU HAVE A SAFE
WORKING ENVIRONMENT WHILE
USING YOUR SAFE JACK ACCESSORIES

IT'S ALL ABOUT SAFETY

WHEEL CHOCKS – 2 PAIRS



PART No. 14410

We all know that Wheel Chocks should be used **EVERY** time a vehicle is raised with a jack.

These compact, nesting Wheel Chocks take up very little space and can be stowed in the bottle jack or jack stand kit bags.

The unique design allows the chocks to be linked together by chain to keep them from skidding or sliding.

The kit includes 4 chocks (Two Pairs) and two sets of chain. Steel construction and bright yellow powder coated finish make these durable and highly visible.

COMPACT JACK STAND BASE



PART No. 14170

If you've ever jacked your vehicle up, you've seen this message:
"Warning! To avoid injury or death, support the load with a suitable support"

You are always going to feel a lot safer getting under a vehicle when you know it's supported by a jack stand, rather than just the jack.

Combine the jack stand base with the Bottle Jack Recovery Kit to give yourself all the right tools to lift and support a vehicle safely.

PART No. 14180

Compact Jack
Stand Adaptor



Safe Jack

PROQUIP
VALUE ADDED PRODUCTS

Pro Quip International
14 London Drive
Bayswater VIC 3153
Tel: (03) 9761 1110
Email: sales@proquip.com.au

www.proquip.com.au