


AUSTRALIAN INSTALLATION INSTRUCTIONS

DIY Brake Control Installation Kit

Part No. 47275

IMPORTANT: Read the following instructions carefully before attempting to install the brake control. If you have any concerns with this product or the installation process, our technical support team can assist you. Call (03) 9761 1110



1. Use the blue butt splice (E) to connect the red wire (A) to the stop lamp switch lead on the brake control. Connect the other end of red wire to the stop lamp switch in the vehicle using the splice connector (F).
2. Use a yellow butt splice (G) to connect the blue wire (B) to the trailer brake lead on the brake control. Route the other end of the blue wire to the trailer connector (H) at the back of the vehicle.
3. Use a yellow butt splice (G) to connect the white wire (D) to the ground lead on the brake control. Route the other end of the white wire to the vehicle's battery. Use the ring connector (I) to connect the white wire to the battery's negative terminal.
4. Use a yellow butt splice (G) to connect the black wire (C) to the power lead on the brake control. Route the other end of the black wire to the vehicle's battery. Use the fuse assembly (J) to connect the black wire to the battery's positive terminal.
5. Use zip ties to secure loose wires as needed.

EXCLUSIVE AUSTRALIAN DISTRIBUTORS:



Pro Quip International

14 London Drive, Bayswater, Melbourne 3153 Australia
Tel: +61 3 9761 1110 Fax: +61 3 9761 1565
Email: sales@proquip.com.au

www.proquip.com.au

**HOPKINS
MANUFACTURING
CORPORATION**



DIY Brake Control Installation Kit Instruction Sheet