

Technical Sheet

PROPULSTATION®

Mobile 12/24V



Explanation of Amps

Cranking amps (CA)

This is the power (amperage) supplied by the Booster's battery at the clamps during a 10 second start at room temperature (18-20°C).

Peak Amps (PA)

This is the power (amperage) supplied by the Booster's battery during a short-circuit at a fraction of a second.

Points of Interest

The PROPULSTATION®, used in accordance with the instruction manual, is perfectly safe for the onboard electronics of your vehicle. The PROPULSTATION® is also perfectly compatible with hybrid vehicles.

Technical & logistic specifications

	PPS 12/24V 3200/1600CA	PPS 12/24V 6400/3200CA
Part No. - Booster	560000	560001
Voltage (DC)	12/24V	12/24V
Cranking amps (CA)	3200/1600 A	6400/3200 A
Peak amps (PA)	7750/3875 A	15550/7750 A
Number of batteries	2	4
Starting cable length	2.10 m	2.10 m
Radaflex® Welding cable size	70 mm ²	70 mm ²
Type of clamps	850 A	850 A
Length of the clamps	215 mm	215 mm
Opening of the clamps	54 mm	54 mm
12V Outlet	✗	✗
Reverse polarity system	✓	✓
Power fuse	500 A	500 A
Auxiliary connector for cables	●	●
Net weight Booster	69 kg	82.5 kg
Dimensions Booster (cm)	50 x 54 x 110	50 x 54 x 110
Dimensions of the packing box (cm)	52 x 55 x 115	52 x 55 x 115


Part No. - Workshop station AC	ACM	ACM
With an automatic electronic charger	7 A	7 A
Weight	2 kg	2 kg
Dimensions (cm)	28 x 11 x 13	28 x 11 x 13
Part No. - Vehicle station DC	DCM	DCM
With a cable and one-way diode	5 m	5 m
Weight	1.75 kg	1.75 kg
Dimensions (cm)	28 x 10 x 13	28 x 10 x 13

2 versions



LEGEND ✓ yes ✗ no ● option ● on demand

Recommended Boosters for professional uses



Power - HP	12V Applications							24V Applications				
	< 125	150	175	250	300	350	500	100	250	500	1000	1500
PPS 12/24V - 3200/1600CA	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■
PPS 12/24V - 6400/3200CA	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■	■ ■

Legend
 ■ ■ Intensive
 ■ Normal

Caution

The conditions when starting a vehicle can vary the results, such as: vehicle's condition, engine type (petrol or diesel) and power, presence of battery in vehicle or not, temperature, frequency of use ... These conditions can all influence the jump start's efficiency.

Chart for your information - Manufacturer's advice.

Our AGM **batteries** with pure lead are extremely efficient thanks to their ability to deliver energy at high amperage almost instantaneously (cranking amps is what is required to make the vehicle start).

Spare part's reference:
 ■ PPS 12/24V-3200/1600CA: **862520**
 ■ PPS 12/24V-6400/3200CA: **862160**

The **internal fuse** protects the batteries against short-circuits.

Spare part's reference: **862006**



The single-piece moulded **case** in 5mm thick polyethylene is unbreakable, with a lifetime warranty, and ensures excellent resistance to shocks and everyday use.

The 5-pin **contactor** ensures a simultaneous and optimal recharge of your Booster's batteries and makes the storing of the Booster easier thanks to two powerful magnets.

Spare part's reference: **522603**

Starting cables (double insulated) with an optimal length and extreme flexibility benefit from a high conductivity as well as a perfect shape resistant to frequent handling.



An accurate and illuminated **voltmeter** indicates the charging level of the Booster, the functioning of the charger as well as the health of the alternator of the vehicle.

Spare part's reference:
 ■ voltmeter: **812003**
 ■ push button: **832002**



The **clamps** have been designed ergonomically with curved jaws with an extra wide opening, as well as optimised security and performance. They are entirely insulated and fitted with a copper bridge which ensures the diffusion of the current on both bronze jaws. The blue clamp is equipped with an LED lamp for easier and safer use, especially in the dark.

Spare part's reference:
 ■ red clamp: **862703**
 ■ blue clamp: **862704**



Voltage Selector

The **voltage selector**, to select either 12V or 24V voltage, is made up of the most robust industrial connectors on the market.

The selector also serves as a circuit breaker. It comes with a buzzer indicating any reverse polarity. This allows you to connect the clamps safely before applying voltage to the Booster.

Options

Part No.	Description	PPS 12/24V	
		3200/1600CA	6400/3200CA
860022	Auxiliary grey connector built on the Booster	●	●
860055	Easy Grip 0.5m cable with moto clamp and F600 clamp	●	●
860056	Easy Grip 0.5m cable with 650A clamp and F600 clamp	●	●

Legend

- Available
- Not recommended
- Not available



Pro Quip International
 14 London Dve Bayswater VIC 3153 Australia
 Tel: (03) 9761 1110 Email: sales@proquip.com.au
www.proquip.com.au

